



**DIFFERENTIAL  
PRESSURE**

**TRANSCAT**

▶ Visit us at [Transcat.com](http://Transcat.com)!

35 Vantage Point Drive // Rochester, NY 14624 // Call 1.800.800.5001

**SERIES  
475**

MADE IN



U. S. A.

**ACCURACY  
 $\pm 0.5\%$  FS**

**RUGGED  
ALUMINUM  
METAL  
HOUSING**

**ONE TOUCH™  
CALIBRATION  
TECHNOLOGY**

**For use with  
Natural Gas**



**MANOMETER**

**SPECIFICATIONS**

**Service:** Air and compatible gases.

**Wetted Materials:** Consult factory.

**Accuracy:** ±0.5% FS, 60 to 78°F (15.6 to 25.6°C); 1.5% FS from 32 to 60°F and 78 to 104°F (0 to 15.6°C and 25.6 to 40°C). **Pressure**

**Hysteresis:** ±0.1% of FS.

**Pressure Limits:** See chart.

**Temperature Limits:** 0 to 140°F (-17.8 to 60°C).

**Compensated Temperature Limits:** 32 to 104°F (0 to 40°C).

**Storage Temperature Limits:** -4 to 176°F (-20 to 80°C).

**Display:** 4-digit LCD (.425 H x .234 W digits).

**Power Requirements:** 9 volt alkaline battery. Battery included but not connected. **Weight:** 10.8 oz (306 g).

**Process Connections:** Two barbed connections for use with 1/8" or 3/16" I.D. tubing. Two compression fittings for use with 1/8" I.D. x 1/4" O.D. tubing (for 100 psi or higher pressure ranges).

**Agency Approvals:** CE, FM approved to CLASS 1, DIV. 2 GROUPS ABCD/T4 Ta = 70°C.

Model	Pressure Ranges	Max. Pressure
475-000-FM	0 to 1.000 in w.c. (0 to .2491 kPa)	5 PSI (34.5 kPa)
475-0-FM	0 to 4.000 in w.c. (0 to 0.996 kPa)	5 PSI (34.5 kPa)
475-1-FM	0 to 10.00 in w.c. (0 to 2.491 kPa)	10 PSI (68.9 kPa)
475-2-FM	0 to 20.00 in w.c. (0 to 4.982 kPa)	10 PSI (68.9 kPa)
475-3-FM	0 to 40.00 in w.c. (0 to 9.96 kPa)	30 PSI (207 kPa)
475-4-FM	0 to 20.00 in w.c. (0 to 4.982 kPa)	30 PSI (2.07 bar)
475-5-FM	0 to 40.00 in w.c. (0 to 9.96 kPa)	60 PSI (4.14 bar)
475-6-FM	0 to 200.0 in w.c. (0 to 49.82 kPa)	60 PSI (4.14 bar)
475-7-FM	0 to 200.0 in w.c. (0 to 49.82 kPa)	150 PSI (10.3 bar)
475-8-FM	0 to 10.00 PSI (0 to .6895 bar)	200 PSI (13.8 bar)
	0 to 20.00 PSI (0 to 1.379 bar)	
	0 to 30.00 PSI (0 to 2.069 bar)	
	0 to 100.0 PSI (0 to 6.895 bar)	
	0 to 150.0 PSI (0 to 10.34 bar)	

**OPERATING INSTRUCTIONS**

**ON/OFF:**

Press ON/OFF to turn the unit on. Press and hold ON/OFF for about 2 seconds to turn it off. Device will automatically shut off after 20 minutes if not in use. **ZERO:**

Vent both pressure ports to atmosphere. Press ZERO button until the LCD displays "----" then release it. The LCD reads 0 if the zero offset is less than 10% of FS. **UNITS:**

To change units, press both ON/OFF and ZERO buttons simultaneously. **BATTERY:**

Remove retaining screws on end cap at base of instrument to replace battery when LOW BAT is displayed. Use 9 V alkaline battery DURACELL® MN 1604, Energizer® 522, or Energizer® EN22.



Enclosure parts are constructed of plastic. When cleaning the exterior use a damp cloth to avoid electrostatic sparking.

Enclosure parts are constructed of aluminum. Enclosure must be protected from mechanical friction and impact with iron/steel to prevent ignition capable sparks.



DWYER INSTRUMENTS, INC.  
MICHIGAN CITY, IN 46360 email: [info@dwyermail.com](mailto:info@dwyermail.com)  
<http://www.dwyer-inst.com>



02-443418-10 Rev. 5